

HabiStat[™] NOVA ACTIVATION SYSTEM

INSTALLTION AND SET UP INSTRUCTIONS



- A: Pump rate adjustment
- B: Power on / off
- C: Lock. Push and hold to lock. Push and hold to unlock.

- 1. Install Panel in appropriate location.
- 2. Attach incoming water source.
- 3. Attach outgoing line (with shut off).
- 4. Verify water flow rates 7 gpm.

a. Adjust water regulator as required.

- 5. Place chemical draw tubes in appropriate containers.
- Never mix undiluted Activator and Base together outside of the Activation chamber.
 With system charged with water, set pump rate to 100 and fill the activation chamber.
- 7. Set desired PPM based on chart below.
- 8. Run treated solution into a pail and verify ORP and Active PPM.
- 9. Check ORP and ppm regularly.

HABISTAT [™] / NOVA [™] ACTIVATION SYSTEM*		
METER SETTINGS = 1 PULSE PER GALLON CONTROLLER SETTING: COUNT = 1, TIME = 7		
PUMP SETTING	ACTIVE PPM	WATER REGULATOR MAX FLOW RATE
100	200	7 gpm
50	100	14 gpm
25	50	28 gpm

*All activation done under water pressure. For best results, use water hardness of less than 5 gpg. Source water treated with H2O2 may affect ORP levels.

For more information, call Acepsis[™] or your local representative.

f in D

ACEPSIS[™], LLC is an animal health based company that is focused on the development of state-of-the-art animal hygiene technologies. Our Company's mission is to apply innovative animal hygiene technologies into the agricultural and veterinary market sectors.

ACEPSIS[™], LLC | 713 North Main Street | Lodi, WI 53555 (608) 203-5535 | info@acepsis.com | www.acepsis.com © 2024 Acepsis[™], LLC. All rights reserved.



ACE L212